

Modify dvswitch for the AMBE3000F

- Ssh into your raspberry-pi with user/password.
- In the terminal you get enter the following commands:

```
sudo -i
wget https://www.combitronics.nl/download/Analog\_Bridge
cd /opt/Analog_Bridge
mv Analog_Bridge Analog_Bridge.bak
cp /home/[your user here]/Analog_Bridge .
chmod +x Analog_Bridge
```
- After this, reboot the device, and the newest version of AMBE3000 / DVStick30 works on it.

73's Ruud, PE1MSZ

Note: the original file, now saved as Analog_Bridge.bak is for the AMBE3000R, and can be copied back if needed.

Follow these instructions carefully, and as usual, this is at your own risk.